



Podešavanja ASUS AAM6010EV-T4

Otvorite *Internet Explorer* ili neki drugi web browser i ukucajte adresu <http://192.168.1.1>. Nakon učitavanja stranice sa slike, ukucajte **Admin** za *Username*, i **Admin** za *Password* polje. Kada upišete user/pass, kliknite na dugme *Log in*.

The screenshot shows a web browser window with a title bar that reads "Please Log In to continue.". The main content area is a simple login form with the heading "Log In" centered above two input fields. The first field is labeled "Username:" and contains the text "Admin". The second field is labeled "Password:" and contains a series of black dots. Below the input fields is a "Log In" button. The entire form is enclosed in a thin black border.

Nakon uspešnog logovanja dobijate glavni ekran na kome je ispisan status uređaja. U meniju na vrhu stranice odaberite opciju *Setup*. Nakon prelaska u meni *Setup*, u meniju sa leve strane odaberite opciju *New Connection*.

U polje *Name* upišite naziv konekcije (ovo je bitno jedino ADSL uređaju, možete upisati tekst koji želite, u našim primerima je to tekst **Gama**). Iz polja *Type* odaberite opciju **PPPoE**. Proverite da li su uključene opcije *NAT* i *Firewall*.

U koloni *PPP Settings* nadjite polja *Username* i *Password* i upišite korisničko ime i šifru za vašu ADSL konekciju. U polju *Authentication* odaberite opciju **PAP**. U polje *MTU* upišite **1400** i proverite da li je uključena opcija *Enforce MTU*.

U koloni *PVC Settings* nadjite polja *VPI* i *VCI*. U polje *VPI* upišite **8**, a u polje *VCI* upišite **35**.

Kada završite sa podešavanjem parametara, kliknite na dugme *Apply*.

| | | | | | | |
|-----------------------|---|-------|----------|-------|--------|------|
| ADSL Modem | HOME | SETUP | ADVANCED | TOOLS | STATUS | HELP |
| LAN Setup | PPPoE Connection Setup | | | | | |
| LAN Configuration | Name: <input type="text" value="Gama"/> Type: <input type="text" value="PPPoE"/> Sharing: <input type="text" value="Disable"/> | | | | | |
| Firewall/NAT Services | Options: <input checked="" type="checkbox"/> NAT <input checked="" type="checkbox"/> Firewall VLAN ID: <input type="text" value="0"/> Priority Bits: <input type="text" value="0"/> | | | | | |
| WAN Setup | | | | | | |
| New Connection | | | | | | |
| Modem | PPP Settings | | | | | |
| Log Out | Username: <input type="text" value="username"/> Password: <input type="password" value="••••"/> | | | | | |
| | Idle Timeout: <input type="text" value="60"/> secs Keep Alive: <input type="text" value="10"/> min | | | | | |
| | Authentication: <input type="radio"/> Auto <input type="radio"/> CHAP <input checked="" type="radio"/> PAP | | | | | |
| | MTU: <input type="text" value="1400"/> bytes | | | | | |
| | On Demand: <input type="checkbox"/> Default Gateway: <input checked="" type="checkbox"/> | | | | | |
| | Enforce MTU: <input checked="" type="checkbox"/> Debug: <input type="checkbox"/> | | | | | |
| | PPP Unnumbered: <input type="checkbox"/> LAN: <input type="text" value="LAN group 1"/> | | | | | |
| | <input type="button" value="Connect"/> <input type="button" value="Disconnect"/> | | | | | |
| | <input type="button" value="Apply"/> <input type="button" value="Delete"/> <input type="button" value="Cancel"/> | | | | | |

Nakon podešavanja, iz glavnog menija odaberite opciju *Tools*, a nakon toga iz menija sa leve strane odaberite opciju *System Commands*. Nakog toga kliknite na dugme *Save All* i sačekajte da se snime podešavanja uređaja. Kliknite na dugme *Restart* i sačekajte da se uređaj restartuje. Nakon restarta, uređaj će automatski uspostaviti vezu.

| | | | | | | |
|-----------------|--|-------|----------|-------|--------|------|
| ADSL Modem | HOME | SETUP | ADVANCED | TOOLS | STATUS | HELP |
| System Commands | System Commands | | | | | |
| Remote Log | System Commands allow you to carry out basic system actions. Press the button to execute a command. | | | | | |
| User Management | | | | | | |
| Update Gateway | | | | | | |
| Ping Test | | | | | | |
| Modem Test | | | | | | |
| Log Out | | | | | | |
| | <input type="button" value="Save All"/> | | | | | |
| | Press this button in order to permanently save the current configuration of the Gateway. If you do restart the system without saving your configuration, the Gateway will revert back to the previously saved configuration. | | | | | |
| | <input type="button" value="Restart"/> | | | | | |
| | Use this button to restart the system. If you have not saved your configurations, the Gateway will revert back to the previously saved configuration upon restarting. NOTE: Connectivity to the unit will be lost. You can reconnect after the unit reboots. | | | | | |
| | <input type="button" value="Restore Defaults"/> | | | | | |
| | Use this button to restore factory default configuration. NOTE: Connectivity to the unit will be lost. You can reconnect after the unit reboots. | | | | | |